




DECESPUGLIATORE BATTERIA LITIO G-DEB40

CORDLESS BRUSHLESS BRUSH CUTTER G-DEB40 •
DEBROUSSAILLEUSE A BATTERIE G-DEB40 • DESBROZADORA
BATERÍA LITIO G-DEB40

Spare Parts

Art.nr. : 1492030





REF.	Code	Description
1	7357667	MOTORE COMPLETO DECESP. COMPLETE ENGINE • MOTEUR COMPLET • MOTOR COMPLETO
2	3150753	PROTEZIONE TAGLIO CUT PROTECTION • PROTECTION COUPE • PROTECCIÓN CORTE
3	5951466	GHIERE FISSALAMA E DADO LOCK RINGS AND NUT • BAGUES FIXATION ET ÉCROU • FIJALAMA Y TUERCA
4	5951467	IMPUGNATURA CENTRALE CENTRAL HANDLE • POIGNÉE CENTRALE • EMPUNADURA CENTRAL
5	7357668	COMANDO INTERUTTORE SWITCH COMMAND • COMMANDE INTERRUPTEUR • MANDO INTERRUPTOR
6	3150754	TRACOLLA SHOULDER STRAP • BANDOULIÈRE • CORREA
7	7357669	SCHEDA ELETTRONICA ELECTRONIC BOARD • CARTE ÉLECTRONIQUE • TARJETA ELECTRÓNICA
8	5951468	RACCORDO TUBI E VOLANTINO PIPE CONNECTOR & HANDWHEEL • RACCORD TUBES ET VOLANT • ACOPLE TUBOS Y VOLANTE
9	3150755	ASSIEME SCOCHE SUPERIORI UPPER SHELLS ASSY • ENSEMBLE COQUES SUPÉRIEURES • CONJUNTO CARCASAS SUPERIORES